
Name: - Mahesh Shah

Course: - B.Sc. (H) Computer Science


Roll No.: - 2022127

Practical Networking: -


Q2. To study and perform PC to PC communication.



- Q3. To create Star topology using Hub and Switch.
- (i) Using Switch




(ii) using Hub




Q4. To create Bus, Ring, Tree, Hybrid, Mash topologies.


(i) Bus Topology




(ii) Tree Topology





(iii) Hybrid Topology





(iv) Mash Topology





Q5. Perform an initial Switch configuration.



→ Name

```
Switch>enable
Switch#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config)#hostname myswitch
myswitch(config)#exit
myswitch#
%SYS-5-CONFIG_I: Configured from console by console
myswitch#
```

password

```
myswitch>enable
myswitch#configur terminal
Enter configuration commands, one per line. End with CNTL/Z.
myswitch(config)#enable password my123
myswitch(config)#exit
```

Q6. Perform an initial Router configuration.

Host Setting

```
Router(config-if) #hostname Mahesh
Mahesh(config) #enable secret MaheshShah
Mahesh(config) #enable password Mahesh123
Mahesh(config) #
```

Set a message of the day (MOTD) banner for the users.

```
Mahesh(config) #
Mahesh(config) #banner motd $
Enter TEXT message. End with the character '$'.
My name is Mahesh Shah
$
```


To configure the Line Control password


```
Mahesh(config-line) #line con 0
Mahesh(config-line) #password mahesh123
Mahesh(config-line) #login
Mahesh(config-line) #exit
Mahesh(config) #
```

Enable secret follow the below commands:


```
Mahesh(config) #line con 0
Mahesh(config-line) #enable password cisco
Mahesh(config) #enable secret mahl23
Mahesh(config) #service password-encryption
Mahesh(config) #exit
Mahesh#
%SYS-5-CONFIG I: Configured from console by console
```

Q7. To implement Client-server Network.







→ Step 1. In any pc go to web server.



-> Step 2. Enter IP address of server connected to your switch in web server URL. Then press GO.



Q8. To implement connection between devices using router.



Router Config

